Notice
For the need of technical improvement and system upgrade,
information contained herein may be subject to change
from time to time without prior notice.

Copyright © 2009
All Rights Reserved.
Manual Edition 1.0, July. 2009
Printed in China

Edifier
www.edifier.com
EDIFIER INTERNATIONAL LIMITED
Made in China

Edifier

English

R600USB Multimedia Speaker

User's Manual

Please carefully read this manual before operating the system

IMPORTANT SAFETY INSTRUCTION

Thank you for purchasing this Edifier product. For generations, Edifier tries to provide powered speaker products to satisfy the need of our end customers, even the most demanding ones. This product can add to your home entertainment, personal computer, and mini home theater great sound performance. Please read this manual carefully to obtain the best of this system.

The lightning flash with arrowhead inside the triangle, is intended to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of a sufficient magnitude to constitute a risk of electric shock to persons.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

To prevent the risk of electric shock, do not remove cover (or back).No user-serviceable Parts inside. Refer ervicing to qualified Service personnel only.

The exclamation point inside the triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

SAFETY INSTRUCTIONS

Please read all the instructions herein.
Please retain this manual safely for future reference.
Please heed all safety warnings.
Please install in accordance with the manufacturer's instructions.
Please adjust the volume control to a comfortable level to avoid damaging your hearing and the system.

- Do not expose this apparatus to rain or moisture.
- Do not use the speakers near water, and do not immerse them in any liquid or pour any liquid on them.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- For added protection during lightning storms, unplug the speakers from the electrical outlet and turn off the computer.
- Unplug this apparatus when unused for long periods of time.
- Place the speakers away from all heat sources, such as heaters, stoves, and direct sunlight.
- Do not block the openings in the speaker cabinets. Never push objects into speaker vents or slots. Prevent risk of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.
- Place the speakers in a stable location so that it will not fall causing damage to the speakers or bodily harm.
- Unplug the speakers from the computer and from the electrical outlet before cleaning them with a damp cloth.
- Servicing is required when the apparatus has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. Refer all servicing to qualified service personnel only.

ILLUSTRATIONS AND FUNCTIONAL DEPICT

Box content

- 1 × Active speaker (with cable)
- 1 × Passive speaker (with cable)
- 1 × User's manual

Illustrations and functional depict

1. Passive speaker
2. Active speaker
3. Tweeter
4. Bass driver
5. Bass reflex port
6. Wire clip
7. In line control pad
8. Volume up
9. Volume down
10. Mute key
11. Power indicator
12. USB plug

Warnings:

•Refer to qualified personnel for servicing.
•Please remove the USB plug from your PC / laptop if the system is unused for long period of time.
•Please do not expose the system to rain or moisture.

SPECIFICATION

Operational guidance

1.Connecting the speakers
First of all connect the active speaker to the passive speaker. Be sure you connect the color coded cable to the right wire clip.
2.Connect to PC
Connect the USB connecting cable attached to the back panel of the active speaker to your PC/laptop.
If you connect the system to your PC / laptop for the first time, all required USB device drivers would be installed automatically, and this may take some time.
3. Play music
Adjust the volume to a comfortable level, and then you're ready to enjoy the music loaded in your computer.

Note: R600 USB can only work perfectly with Windows 2000 / XP / Vista / Mac OS X and more advance operating systems.

Specification

Power output: ——————Satellite: RMS 1.2W × 2 (THD = 10%, f 0 = 1 kHz)
Signal to noise ratio: ——— ≥80 dBA
Distortion: ————————— ≤2%
Input type: ——————————USB
Input sensitivity: ——————1000±50 mV
Adjustment: ——————————Master volume control keys on the in-line control pad
Bass unit: ——————————4 inch (106mm), magnetically shielded, 4ohm
Tweeter unit: ——————————Φ13mm silk dome tweeter, magnetically shielded, 4ohm
Dimension: ——————————140 × 226 × 196 mm (W x H x D)
Net weight: ——————————Approx 2.5 kg
Gross weight: ——————————Approx 3.2 kg

If you have any further questions or concerns regarding Edifier Products
Please visit our website at: www.edifier.com,
or email Edifier Support for further assistance at: main@edifier.com,
If you prefer, you may contact us by phone, Toll Free: 1-877-EDIFIER (334-3437).